## OPERATING INSTRUCTIONS

-SWITCHING ON-PLUG THE SUPPLY CORD INTO THE POWER OUTLET. SLIDE THE ON/OFF SWITCH FORWARD AND TEHN PRESS IT AS FAR AS IT WILL GO.

-SWITCHING OFF-RELEASE THE ON/OFF SWITCH

SWITCHING ON/OFF AND LOCKING THE SWITCH -NOTE: IF THE TOOL IS UNPLUGGED FROM THE ELECTRIC SUPLY WHILE THE ON/OFF SWITCH IS LOCKED IN THE ON POSITION AND SUBSEQUENTLY PLUGGED BACK INTO THE ELECTRIC SUPPLY, THE TOOL WILL NOT RESTART, THE SWITCH LOCK MUST BE RELEASED WHILE THE TOOL IS DISCONNECTED FROM THE ELECTRIC SUPPLY BEFORE THE SUPPLY CORD IS AGAIN PLUGGED INTO THE POWER OUTLET.

-SWITCHING ON AND LOCKING THE SWITCH-(1) PLUG THE SUPPLY CORD INTO THE POWER OUTLET. (2)SLIDE THE ON/OFF SWITCH FORWARD SLIGHTLY AND, WHILE PRESSING IT DOWN, SLIDE IT FURTHER FORWARD UNTIL IT LOCKS IN POSITION.

-SWITCHING OFF AFTER LOCKING THE SWITCH-(1) PRESS THE FRONT PART OF THE ON/OFF SWITCH DOWN (THE LOCK THEN RELEASES).