



Pretzel/Pizza Warmer CAUTION...MACHINE GET'S HOT!

1. Place on sturdy flat surface
2. Plug directly into an outlet
3. Fill water pan with hot water, DO NOT overfill the pan
4. Turn the heat switch to the on position
5. Turn the heat control to high and preheat the cabinet for 15 minutes
6. Once preheated turn the temp control to the desired setting
7. Add pizza or pretzels
8. Turn light switch to the on position for the lights and rotating rack to operate
9. Check the water level periodically through out use, to ensure you do not run out of water.

Note: If you start with hot water, the unit will generate steam in about 15 minutes then the product can be put inside. If loading pizza, place it in the cabinet straight from the oven.

When done with unit, turn off and unplug and wait for the unit to cool down. Empty all remaining food products, and empty water.

Crown Rental is responsible for the main washing of the machines. You are not required to do any washing.