



Shake Machine

1. Plug machine directly into an outlet
2. Thaw out shake mix before pouring into the hopper (10-12 hours)
3. Pour mixture into hopper
4. Turn power on (lightning bolt)
5. Turn Auger on, if using the 2-section machine turn both augurs on (swirly)
6. Turn freezing system on (snowflake)
7. Machine will take roughly 45 minutes to 1 hour to fully shake up
8. If mixture is to frozen switch the freezing switch to cooling switch (snowflake to wave)
9. Machine needs to be kept out of the sun and heat.

When done with either machine, unplug machine, drain all remaining liquid from hoppers, rinse hopper out with water.

Crown Rental is responsible for the main washing of the machines. You are not required to do any washing.



Slushy Machine

1. Plug machine directly into an outlet
2. Mix 2 gallons of water with $\frac{1}{2}$ gallon of slushy mix
3. Pour mixture into hopper
4. Turn power on (lightning bolt)
5. Turn Auger on, if using the 2-section machine turn both augers on (half circle with arrow)
6. Turn freezing system on (snowflake)
7. Machine will take roughly 45 minutes to 1 hour to fully slush up
8. If mixture is to frozen switch the freezing switch to cooling switch (snowflake to rain drop)
9. Machine needs to be kept out of the sun and heat.

When done with either machine, unplug machine, drain all remaining liquid from hoppers, rinse hopper out with water.

Crown Rental is responsible for the main washing of the machines. You are not required to do any washing.