



Automatic Sno Cone Machine

Operation

1. Plug unit into a 120 volt outlet
2. Turn power on
3. Wait for the motor to come to full speed (about a minute or so)
4. Fill the gooseneck to within an inch of the top with ice cubes
5. Push the handle down against the ice in the gooseneck. Apply firm pressure to the gooseneck and press/hold the motor button down.
6. Be aware that under normal operating conditions that motor will become warm. A surface temperature of 150 degrees F is normal
7. Keep unit in a shaded area if outside in sun

Cleaning

1. Turn off and unplug the unit
2. Empty all remain ice from the unit
3. Wipe away any Sno Cone Juice splashes
4. Return both sno cone scoops, hose and pumps

Crown Rental is responsible for the main washing of the machines. You are not required to do any washing.