



To reverse position of jaws . . .

1.




Spread jaws apart with thumb on side where ring is split. Slide jaws away from handle about 1/2 jaw length. It is not necessary to remove spring ring.

2.




3.



Maintain grip on jaws. Keep jaws in firm contact with body of wrench turning jaws 180°.

4.



Push jaws back against hex shoulder of body.