

HOW TO USE THE DRAIN CLEANING BLADDER;

1. ATTACH THE DRAIN CLEANING BLADDER TO A HOSE CONNECTED TO A COLD WATER FAUCET.
2. PLACE INTO THE CLOGGED DRAIN - A MINIMUM OF 6 INCHES.
3. TURN ON THE COLD WATER SLOWLY TO FULL PRESSURE. AS THE WATER FILLS THE DRAIN CLEANING BLADDER, THE UNIT WILL EXPAND TO FIT SNUGLY AGAINST THE WALLS OF THE PIPE. WHEN THE UNIT IS FULLY INFLATED, WATER WILL BE FORCED OUT THE END OF THE DRAIN CLEANING BLADDER TO PUT PRESSURE ON THE CLOG AND PUSH IT THROUGH THE DRAIN PIPE.
4. TURN THE WATER OFF BEFORE REMOVING THE DRAIN CLEANING BLADDER. DO NOT LEAVE BLADDER UNATTACHED WHILE WATER IS RUNNING. IF WATER BACKS UP PAST THE BLADDER, SHUT THE WATER OFF IMMEDIATELY.

CAUTION - DO NOT USE THE DRAIN CLEANING BLADDER:

- WITH WATER PRESSURE ABOVE 50 PSI
- IN TOILETS
- WITH HOT WATER
- IF CHEMICALS HAVE BEEN USED IN AN ATTEMPT TO CLEAR DRAIN.
- UNLESS IT CAN BE INSERTED COMPLETELY INTO THE DRAIN LINE.